

Ez-Tex G5 Operational Instructions

1. Before attempting to use the G5 check material manufacturer for mixing and spraying instructions.
2. Check the G5 Hopper and make sure it is absolutely free from foreign debris.
3. Pull pressure regulator knob and turn counterclockwise all the way until a stop.
4. Select the proper spray tip for the finish you need and install onto the gun.
5. Close air valve on the gun to stop the air from flowing out.
6. Connect material hose and air hose to the G5.
7. Connect material hose and air hose to gun.
8. Mix the material you're working with.
9. Check material viscosity with funnel supplied, make sure it flows as thick as possible without lumps.
10. Pour material into hopper.
11. Cover the G5 with the lid supply.
12. Turn on your air compressor and make sure the pressure is not exceeding 100psi.
13. Connect airline to G5 air inlet connector. (A1)
14. Turn pressure regulator clockwise until material starts flowing in the hose. (A2)
15. Trigger gun to purge air from hose spraying into a different bucket.
16. Open air valve to allow the material to atomize.
17. Spray on a test surface making sure you have the desired spray finish.
18. Lock pressure regulator on your setting by pushing knob to secure setting.
19. For cleaning go back to step # 12 and flush with water, when clean insert 1 blue ball into the hose run with water until hose is clean, if not clean repeat cleaning steps.

- Note:** A. Always practice with clean water before supplying any material to the G5.
B. Always test spray before applying on the finish surface.
C. Never use material that dries in less than 30 minutes.

