

When using the Rotortex with decorative cement finishes what do I need to know and do?

1. We recommend to prime the machine with Slick-Tex or cement slurry (cement lime & water)
2. If using a premix bag with dry polymer we recommend after mixing the material wait 3-5 minutes to allow material get it's proper moisture re mix adding very little water. This will increase drying time and allow better machine performance.
3. If using a wet polymer you must add retarder to material to increase drying time.
4. Use only one bag at the time to allow fresh material to flow through the system. Never fill to the top of the hopper with material, it will dry in the machine before it will be complete used.
5. If you purchase the machine with an air compressor you must remove it from the unit before use to eliminate vibration on the machine. Vibration will result in material separation and difficult material flow.
6. Never use less than a 1/4" spray tip with aggregated material. You can adjust the spray finish by adjusting the air to high or low flow.
7. When you stop spraying you must turn the machine off, and keep spraying until no material sprays out from the gun. This will eliminate material pack-up at the gun tip, and allow easy machine start.
8. Never walk away from the machine when there is still material in hopper. It will dry solid.
9. When you finish spraying you must remove stator from main block, and rinse with water.
10. You must remove the tip and needle from the gun and clean it with water, apply grease on the O-ring and reinstall it.
11. For any other questions, please call technical support.